


KÄRCHER

How to use




Slowly move horizontally




Do not incline or move fast-paced: water leakage


Please mind:




Check tank level if water leaks although used correctly



Empty water tank if filled to max



Do not attach upside down



Water in the tank and metal plate can get hot